Instructions for maintenance

© 2007 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7



0-44231-000 K&K Spring see-saw

One-time maintenance									
Check all screw connections; if necessary screw dov		crew down again.	one-time only approx. 4-5 weeks after installation						
	mendations egular mainter	nance		1 x weekly	2 x monthly	1 x monthly	4 x yearly	2 x yearly	1 x yearly
Check clea	nliness of play- and s	afety area, take out	alien elements						
	er component element nections and replace	•	·						
	dation, foundation an	•	construction for						

Please note:

The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)