

## Instructions for maintenance

In addition to the manufacturer-related service instructions, we strongly advise the operator/owner to consider the corresponding prescriptions of the European Standard EN1176-7.



(exemplary colour illustration)

Hill slide (3,50) with starting 041875501 platform 0,20

One-time maintenance

Check all screw connections; retighten, if necessary. Cover the screws with protective screw caps.	once, approx. 4-5 weeks after installation						
Recommended regular inspection and maintenance		once a week	twice per month	once a month	four times a year	twice a year	once a year
Check cleanliness of playing and safety area. Remove any fore object	eign						
Check cleanliness of sliding surfaces, remove protruding parts exchange damaged sliding course coverings	ī						
In case of drying cracks, remove splinters of wood and chamfe sharp edges	er						
Where appropriate, check synthetic surfacing material for damages or severe wear, repair or replace, if necessary							
Check tightness of stand construction: stability of (vertical) pos supports, retighten screw connections, if necessary.	ts or						
Check further structural components for wear and tightness; retighten, if necessary and replace defective parts.							
Check foundations and structural construction for corrosion or decay, repair or replace if necessary							

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).